


# Akushapper ROOM LAYOUT ( All dimensions in Millimeters )



We need to have 2 separate 1 phase 240 vac 16amp or 110vac 20 amp electrical circuits to this point

We also need to have 1 separate 1 phase 240 vac 16 amp or 110vac 20 amp electrical circuit for the vacuum pump

The vacuum pump needs to be installed as close as possible to the machine but away from foam dust – e.g. on the roof of the shaping area